

# INSTRUCTIONS

## OPENING CANS



Watch our quick-start  
video tutorial here:  
[lantana-home.com/video](http://lantana-home.com/video)

1. Before use, make a half turn of the lever in a backwards direction. This ensures that the cutting mechanism is in the open position and ready to take a can.
2. Place the can on a flat and even surface, then slot the wheel of the opener over the rim of the can.

### Tip

**Tip for beginners:** For your first few cans, we suggest that you mark the can lid (or make a small tear in the can label) at the starting position of the opener. This is to give you a visual indication of where to finish cutting - but more on that in step 4, this is just until you get a feel for how the can opener works.

3. Begin turning the lever in a forward direction. As you do this, you will feel the opener grip onto the rim of the can. Continue to turn the lever forwards - the can will rotate as the opener cuts around the rim.

4



4. When you feel a slight 'jolt' and lesser resistance from the lever, this signals that you have cut around the full rim and can stop turning the lever forwards.

**VERY IMPORTANT** - Do not continue to cut around the can more than once. Over cutting may cause burs or slivers.

5. Turn the lever a half turn backwards to release the opener from the can.

5



...CONTINUED

# Lantana<sup>®</sup>

UK

6. Lift the lid away from the can with your fingers to access the can contents.

7. The lid fits neatly back onto the can in case you wish to store the can contents for later.



#### NOTE:

Very occasionally, some can lids may be a little stiff to remove by hand - this can be due to a vacuum inside the can, or sometimes due to excess rubber sealant within the rim.

If you struggle to lift the lid with your fingers, you may also use the bottle opener as a can lid lifter (the metal lip of the opener is specially rounded to snugly fit the can rim)

Simply place the metal lip of the opener underneath the cut you made in the rim and lift the can lid (use the same motion as you would use to take off a bottle cap).

## CLEANING

**VERY IMPORTANT - Not suitable for dishwasher. Do not submerge in water.**

This Can Opener contains precision moving metal parts inside the device. Dishwasher use and water submersion can wash away important internal lubrication and may also lead to eventual rusting. This can cause the opener to cease working.

Please only clean with a well wrung out damp cloth, taking care not to allow water to get inside the cutting mechanism. (With correct use, the cutting mechanism never touches the food, therefore does not require cleaning after use). Allow the surface of the opener to dry thoroughly before storage.

Correct care of this product will allow for years of trouble-free use on 1000s of cans.

...CONTINUED

THE LANTANA 2 IN 1  
SAFETY CAN OPENER  
ALSO FEATURES AN EASY  
TO USE BOTTLE OPENER

## OPENING BOTTLES

UK

1. Place bottle on a sturdy surface and hold it firmly with one hand.
2. Position the steel lip (underneath the head of the opener) under the rim of the bottle cap.
3. Slowly lift the handle, keeping the head of the opener on top of the bottle cap. This motion will lever the bottle cap from the bottle.



## CONTACT LANTANA

For expert advice and a fast & personal response to any questions you may have about this product, please email us at [support@lantana-home.com](mailto:support@lantana-home.com)

Lantana®

lantana-home.com